

INSTRUCTIONS

Drying cabinet ProLine TS 63/TS 93



1. Open the doors



2. Pull out the rails and hang the laundry



3. Close the doors



Automatic



Timed drying

4. Choose program

Choose between Automatic or Timed drying program



5. Start program



6. Drying in process



7. Drying finished



8. Remove laundry



9. Close the doors